

open up old door opening and brick back in the small section to remain at the side. Install timber architraves and plaster up to it

prepare floor and lay additional 50mm screed tapered to the existing ground level outside (stop at lift - this is as the base of the

> new roller shutter door coloured to match the building cladding as near as possible and

## Contractor to provide 30A spur for new lift in location to be agreed

LP SCALE 1:20@A3			@A3	
		DATE 06/23 DRAWN BY NJA		
ad, Camberley (01276 21133)			1-06 REV	