




DO NOT SCALE FROM THIS DRAWING EXCEPT FOR PLANNING PURPOSES.
THE CONTRACTOR IS TO CHECK ALL DIMENSIONS AND LEVELS ON SITE
BEFORE COMMENCING WORK AND NOTIFY THE ARCHITECT OF ANY
DISCREPANCIES.



Block Plan
Scale: 1:500



Site Location Plan
Scale: 1:1250

[illegible]